



KIT PARTS ARE NO ASSEMBLED

NOTES:

1. TO ASSEMBLE, APPLY A DOUBLE LAYER OF TEFLON TAPE, AND A LAYER OF PIPE DOPE TO THE THREADS ON THE PLASTIC FITTINGS AND INSTALL PER THE MANUFACTURER'S INSTRUCTIONS.
2. ASSEMBLY SHALL BE PRESSURE TESTED.



THE CITY OF LYNCHBURG

LPFM— LATERAL

USE WITH THE CITY OF LYNCHBURG STANDARD SPECIFICATIONS ONLY

SCALE:
NOT TO SCALE

REVISION DATE:
12-12-2014

DETAIL #
27.33

SHEET #:
1 OF 1